



How to extend validity by MP_Config2.exe

1. Please turn on the printer. Then please pull out ribbon from the printer. Then shut the cover and push "EJECT" button once.




2. Please execute "MP_Config2.exe" on PC which is connected with printer.

After execution, please click "Refresh" on.



3. Please click on "Set" button and then click on "Complete" button.

After that please click "Close".



4. Then please open cover and install ribbon to use.